



AIO CPU COOLER INSTALLATION



INSTALLATION - INTEL SOCKET


LGA115X/ LGA1200/ LGA1366/LGA1700/ LGA2011/ LGA2066/ LGA2011-V3 Core i3/i5/i9 Pentium Celeron

STEP 1 MOUNTING BRACKETS INSTALLATION




Push the Intel bracket in the slot on the pump unit.

STEP 3 APPLYING THE THERMAL COMPOUND




Remove the cover of the copper plate at the bottom of the pump.



Wipe the CPU's contact surface (using a non-abrasive cloth or a Q-tip as shown in the sample image). On a clean IHS, apply a line of thermal compound and spread it over the whole CPU heat spreader (IHS) with a credit card or something similar.

STEP 4 BLACKPLATE INSTALLATION




Install the backplate for Intel socket to the back of your motherboard. The connector can be adjusted to fit different types of chips.

Peeling off the adhesive tape, align the holes on the motherboard with the holes on the backplate and stick to the motherboard.

Note: The backplate is pre-installed with the Intel connector

STEP 2 INSTALLING THE RADIATOR AND FANS ASSEMBLY INTO THE PC CASE





Attach the assembly of the radiator and the fan(-s) to the PC case with the lock case screws.

Radiator on top (recommended) Vertical placement of the radiator with tubing at the bottom (recommended)

Vertical placement of the radiator with tubing at the top (not optimal)

Radiator at the bottom (should be avoided)

STEP 5 PUT THE PUMP ON MOTHERBOARD



Place the pump onto the CPU's contact surface, ensuring that the holes on the bracket align accurately with the holes on the motherboard. Apply gentle downward pressure to ensure a perfect connection between the contact surface and the pump.

Use the Intel/ AMD screws provided to attach the bracket to the holes on the backplate through the holes of the motherboard.


*For Intel LGA 2011 original backplate, please use the Intel LGA 2011 Screw provided to attach the bracket to the holes on the backplate through the holes of the motherboard.

STEP 6

PUMP AND FAN CABLES CONNECTION


A. PUMP CONNECTING TO THE HUB

Connect Pump Power connector to the hub's power (fan) header
Connect Pump ARGB connector to the hub's ARGB (led lights) header



B.FAN CONNECTING TO THE HUB

Connect Fan Power connector to the hub's power (fan) header
Connect Fan ARGB connector to the hub's ARGB (led lights) header





C. HUB CONNECTING TO MAINBOARD


The hub come with SATA power cable (a) and PWM/ ARGB controller cable (b) for motherboard connection. See the image for further part identification.

Step 1:
Connect the hub's SATA power cable to the PSU

Step 2:
Connect ARGB header to the 5V ARGB header on the motherboard
Connect the hub's PWM header to the CPU fan header on the motherboard.



ARGB REMOTE CONTROL




After installing the hub controller, you can use the ARGB remote control right away without installation.

1. Turn on LED
2. Turn off LED
3. Dynamic Speed Adjust
Adjust the dynamic speed of the fan. Press SPEED+ to increase and SPEED- to decrease.
4. Brightness Adjust
Adjust static color brightness. Press BRIGHT+ to increase brightness and press BRIGHT- to decrease.
5. Auto mode
Press this key to switch to Auto mode. At auto mode, it plays 80+ dynamic modes in loop, each mode repeat 3 times.
6. Dynamic Mode Adjust
Switch to dynamic mode from static color, or switch between dynamic modes.
7. Direct Color Select
Shortcut key to static colors. When press the specific color key, LED will play the same static color.

TROUBLESHOOTING

- There are 80+ modes of color as following:
- Colorful slow flash
 - Single color gradient
 - Single red, single orange, single yellow, single green, light green, single blue, light blue, single purple, single pink, single blue, light pink.
- In order to change to other lighting mode, either:
- Use the remote to change the color
 - Connect the PC Case Led Wire (if your pc case support)




INSTALLATION - AMD SOCKET

*For AM5 Socket, if you prefer to use your original backplate or your backplate is attached to your motherboard, we also provide 6-32 screws for backplate installation.

AM5, AM4, AM3, AM2+, AM2, FM2+, FM2, FM1, Ryzen R3/R5/R7 APU A4/A6/A8/A10/A12 FX 4/6/8- core Phenom II X2/X3/X4/X6 AthlonII X2/X3/X4 Athlon X4

STEP 1 REMOVING THE ORIGINAL PLASTIC HOLD-DOWN CLAMPS (AMD)




Using Philips-head screwdriver, remove the 4 screws securing the original plastic hold-down clamps around the socket as shown in the image. Keep the hold-down clamps to store them away.

If you have AM5 socket, keep the original AMD® backplate for use in Step 6.

If you have other AMD socket, store your original backplate away and use our backplate.


See the image for further part identification.

STEP 2 MOUNTING BRACKETS INSTALLATION




Push the AMD bracket in the slot on the pump unit.

STEP 4 APPLYING THE THERMAL COMPOUND




Remove the cover of the copper plate at the bottom of the pump.



Wipe the CPU's contact surface (using a non-abrasive cloth or a Q-tip as shown in the sample image). On a clean IHS, apply a line of thermal compound and spread it over the whole CPU heat spreader (IHS) with a credit card or something similar.


STEP 5 BLACKPLATE INSTALLATION



Install the AMD backplate to the back of your motherboard. Peel off the adhesive tape, align the holes on the motherboard with the holes on the backplate and stick to the back of your motherboard.

For AM5 Socket, if you prefer to use your original backplate or your backplate is attached to your motherboard, we also provide 6-32 screws for the next step.

STEP 3 INSTALLING THE RADIATOR AND FANS ASSEMBLY INTO THE PC CASE





Attach the assembly of the radiator and the fan(-s) to the PC case with the lock case screws.

Radiator on top (recommended)
Vertical placement of the radiator with tubing at the bottom (recommended)

Vertical placement of the radiator with tubing at the top (not optimal)

Radiator at the bottom (should be avoided)

STEP 6 PUMP AND BACKPLATE INSTALLATION



Place the pump onto the CPU's contact surface, ensuring that the holes on the bracket align accurately with the holes on the motherboard. Apply gentle downward pressure to ensure a perfect connection between the contact surface and the pump. Use the Intel/AMD screws provided to attach the bracket to the holes on the backplate through the holes of the motherboard.


*For AM5 original backplate, please use the 6-32 screws provided to attach the bracket to the holes on the backplate through the holes of the motherboard.

STEP 7

PUMP AND FAN CABLES CONNECTION


A. PUMP CONNECTING TO THE HUB

Connect Pump Power connector to the hub's power (fan) header
Connect Pump ARGB connector to the hub's ARGB (led lights) header



B.FAN CONNECTING TO THE HUB



Connect Fan Power connector to the hub's power (fan) header
Connect Fan ARGB connector to the hub's ARGB (led lights) header




C. HUB CONNECTING TO MAINBOARD

The hub come with SATA power cable (a) and PWM/ ARGB controller cable (b) for motherboard connection. See the image for further part identification.

- Step 1:
Connect the hub's SATA power cable to the PSU
- Step 2:
Connect ARGB header to the 5V ARGB header on the motherboard
Connect the hub's PWM header to the CPU fan header on the motherboard.



ARGB REMOTE CONTROL



After installing the hub controller, you can use the ARGB remote control right away without installation.

1. Turn on LED
2. Turn off LED
3. Dynamic Speed Adjust
Adjust the dynamic speed of the fan. Press SPEED+ to increase and SPEED- to decrease.
4. Brightness Adjust
Adjust static color brightness. Press BRIGHT+ to increase brightness and press BRIGHT- to decrease.
5. Auto mode
Press this key to switch to Auto mode. At auto mode, it plays 80+ dynamic modes in loop, each mode repeat 3 times.
6. Dynamic Mode Adjust
Switch to dynamic mode from static color, or switch between dynamic modes.
7. Direct Color Select
Shortcut key to static colors. When press the specific color key, LED will play the same static color.


TROUBLESHOOTING

There are 80+ modes of color as following:

- Colorful slow flash
- Single color gradient
- Single red, single orange, single yellow, single green, light green, single blue, light blue, single purple, single pink, single blue, light pink.

In order to change to other lighting mode, either:

- Use the remote to change the color
- Connect the PC Case Led Wire (if your pc case support)



SUPPORT AND SERVICE

Email: notifications@dracaena.io
Phone: +1 (469) 409- 2818
Website: dracaena.io